



2007-2018 Chevy 1500 3.0 Rear Bypass Shocks

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

Rear Parts List:

- 2 – Rear 3.0 Bypass Shocks (33001-202)
- 4 – Reservoir Clamps (25042-020)
- 4 – 1/4 x 1" SHCS (CB1501)
- 4 – 1/4 x 1/2" BHCS (CB2420)
- 1 – Loop Strap (H41078)
- 2 – Fender Washers with 1/4 x 1" bolt, 1/4" nut and 1/4" washer (left side hose)

Tools Required:

- Floor Jack/Jack Stands
- Metric Socket/Wrench Set
- Standard Socket/Wrench Set
- 5/32 & 3/16 Hex Wrench
- Drill and 1/4" Drill Bit
- #15 Torx Bit

2007-2018 Chevy 1500 3.0
DEM PERFORMANCE SERIES



REAR: With the vehicle on level ground, block the front tires. Using a floor jack, raise the rear end and support the frame rails with jack stands for safety. Remove the rear tires. **NOTE: Never work under an unsupported vehicle.**

1. Remove existing rear shocks using a 21mm socket and wrench. Remove the lower nut and bolt, then remove the bolt from upper mount (nut is welded) and remove shocks.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.



2007-2018 Chevy 1500 3.0 Rear Bypass Shocks

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

2. Install King Shocks in the factory mounts using the factory hardware and tighten to factory specs. The bypass tubes will face towards the rear of the vehicle on both sides, shocks are side specific (see photos for proper shock orientation).

Left Side

Right Side

The shock with the longer hose will go on the left side... Shocks should be labeled Left and Right from the factory but always double check and make sure you are installing the shock with the longer hose on the left side.



3. Remove the fender liners on both sides to mark and drill holes for the reservoir clamps. First remove all the Torx head screws with a #15 Torx bit, then remove the fender liners from the vehicle.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.



2007-2018 Chevy 1500 3.0 Rear Bypass Shocks

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

4. Make a mark lined up with the center of the cross member then measure 4" to each side of the center line.



5. Find the center of the two outside lines and use a center punch to mark the location for drilling. Drill 1/4" holes.



6. Place the fender liner back in position on the vehicle to mark for drilling but don't screw back in yet. Mark the two holes, remove from vehicle and drill 1/4" holes. Place the fender liner back on the vehicle, make sure the holes are lined up. Replace all the screws and tighten.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.


This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.



2007-2018 Chevy 1500 3.0 Rear Bypass Shocks

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

7. Attach the reservoir clamps using the 1/4 x 1/2" BHCS. Be sure to use red locktite, tighten with a 5/32" hex wrench.



8. Place the reservoirs in the clamps. Starting with the left side, loop the reservoir into the clamps as shown.



9. Use the provided loop strap, fender washers and 1/4 x 1" bolt with nut to hold the hose to the frame. **(Left side only)** Place loop strap on hose, place oval washer in the recessed oval hole in the frame. Use the 1/4 x 1" bolt and nut with fender washer to attach hose. This step is important to make sure the hose does not rub on tire and leaf spring.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.



2007-2018 Chevy 1500 3.0 Rear Bypass Shocks

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

10. Left side continued... Center reservoir in the clamps and tighten the 1/4 x 1" SHCS using a 3/16 hex wrench.



11. Right side reservoir... Place reservoir in clamps as shown in the photos below.



12. Install the 1/4 x 1" SHCS and snug so the reservoir can still be rotated in the clamps.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.



2007-2018 Chevy 1500 3.0 Rear Bypass Shocks

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

13. Rotate the reservoir towards you so that the hose twists towards the frame. The hose should be laying tight against the frame as shown in the photos below. This is important to make sure the hose does not interfere with the leaf spring. With the hose properly positioned, tighten the clamps.



Left Side

Right Side

**Double Check All Hardware!**

Make sure shocks are installed properly and all hardware is tight. Replace tires, remove jack stands and lower vehicle. Double check all hardware and lug nuts after 100 miles or so and periodically after that as part of routine maintenance.

IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.



2007-2018 Chevy 1500 3.0 Rear Bypass Shocks


King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

KING RECOMMENDED BYPASS ADJUSTER SETTING:

RECOMMENDED TUBE ADJUSTEMENTS:

LEFT & RIGHT SHOCKS ARE THE SAME

1. COMPRESSION TUBE 1
 - 7 REVOLUTIONS OUT FROM FULLY CLOSED
2. COMPRESSION TUBE 2
 - 4 REVOLUTIONS OUT FROM FULLY CLOSED
3. REBOUND TUBE
 - 11.5 REVOLUTIONS FROM FULLY CLOSED



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.