INS-I002 (Rev. A 12/26/19)

Installation Instructions (Page 1)



2012+ Isuzu D-Max/Holden Colorado Rear Shocks

King Shocks 12472 Edison Way Garden Grove, CA 92841 714-530-8701 www.kingshocks.com

<u>Rear Parts List:</u>

2 – 2.5 Piggy Back Rear Shocks (25001-308)

Tools Required: Floor Jack/Jack Stands Metric Socket/Wrench Set Standard Socket/Wrench Set



MADE IN MADE IN MADE INTHE USA FROM THE HIGHEST GUALITY BILLET U. S. A. ALLOY MATERIALS

- **<u>REAR</u>**: With the vehicle on level ground, block the front tires. Using a floor jack, raise the rear end and support the frame rails with jack stands for safety. **<u>NOTE: Never work under an unsupported vehicle.</u>**
- 1. Remove the factory shocks and save all hardware.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.

INS-I002 (Rev. A 12/26/19)



Installation Instructions (Page 2)

2012+ Isuzu D-Max/Holden Colorado Rear Shocks

King Shocks 12472 Edison Way Garden Grove, CA 92841 714-530-8701 <u>www.kingshocks.com</u>

2. Install King Shocks using the factory hardware and tighten to factory specs. Be sure to mount the shocks with the reservoirs oriented as shown in the photos below and the shaft mounted to the axle.





DOUBLE CHECK ALL HARDWARE:

Make sure everything is installed correctly and all hardware is tight. Remove jack stands and lower vehicle to the ground. Recheck all hardware and lug nuts after 100 miles and periodically after that as part of routine maintenance.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.

