



2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

Front Parts List:

- 2 – 2.5 Coilover Shocks (25001-146) or
- 2 – 3.0 Coilover Shocks (33001-207) 
- 2 – Reservoir Brackets (25044-020)
- 2 – Lower Mounting Brackets (25029-001)
- 2 – Axle Bump Spacers (25038-002)
- 4 – Brake Line Support Brackets (25029-002, 003, 004)
- 2 – Hardware Kits (KH02-158)

Tools Required:

- Floor Jack/Jack Stands
- Standard Wrench/Socket Set
- Metric Wrench/Socket Set
- 6mm, 1/8, 5/32, 3/16 Allen Wrench
- Drill and 7/16 Drill Bit
- Sawzall/Grinder


2005 + Ford F250/F350 Coilover Conversion

DEM PERFORMANCE SERIES



FRONT: With the vehicle on level ground, set the emergency brake and block the rear tires. Using a floor jack, raise the front end and support the frame rails with jack stands for safety. Remove front tires. **NOTE: Never work under an unsupported vehicle.**

1. Remove existing shocks. Keep the axle supported with a floor jack during disassembly and installation. First remove the lower mounting bolt using an 18mm socket. Remove upper mounting nut using a 21mm socket. (you may need to hold shock with another wrench to keep it from spinning)



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.



2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

2. Remove ABS/Brake line supports from both sides of the lower coil bracket using a 10mm wrench/socket.
There will be one bracket in front on newer vehicles.



3. With the shocks removed and the ABS/brake lines disconnected, lower the axle and remove the coil springs.



4. Remove the foam bump stop from the mount on frame. Pull the bump stop to the side and down with a firm tug to remove bump stop.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.



2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

5. Remove the bump stop mount from the frame using a 10mm socket.



6. The bump stop mount has a tab sticking out that needs to be tapped flat with a hammer as shown.



7. Reinstall the bump stop mount with the supplied spacer and longer bolt w/washer. Tighten the bolt using a 6mm Allen wrench. Push the bump stop back into the mount making sure it's pushed in all the way.



8. Remove the lower coil mount using an 18mm Socket.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.


This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.



2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

9. Install the supplied lower mounting bracket to the axle where you just removed the factory coil mount. Use the provided 14mm bolt with washer and tighten using a 22mm socket.



10. Using the reservoir bracket as a template carefully mark the holes in the upper coil spring mount. Mark holes, then center punch each hole and recheck the alignment of marked holes with reservoir bracket.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.



2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

11. Use the center punch mark to drill a pilot hole starting with a smaller drill bit - 1/8 or 3/16. Double check your pilot holes with your template to make sure the hole pattern is lining up. Now finish drilling out holes using a 7/16" drill bit.



12. Cut the coil spring locating boss flush with the upper mount. Grind any protruding or sharp edges so the surface is completely flat. Paint the bare metal prior to installing shocks to prevent rusting.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.



This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.




2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

13. Install King Coilover Shocks. Be aware the shocks are side specific, make sure you are installing the shocks on the proper side. Place lower rod end into the new lower mount, tilt shock forward to install the provided 1/2 x 3" bolt with washer and tilt shock back to install washer and nut and tighten.



14. On the left side of some vehicles you will need to move the brake proportioning unit to install the upper mounting bolts. First remove the bolt on the front side of the coil mount using a 13mm wrench/socket. Then find the two nuts located inside the engine compartment and just loosen those nuts to the end of the stud but do not remove. This should give you room to pry the brake unit up enough to install bolts.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.


This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.



2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

15. Place the reservoir mount between the upper mounting plate of shock and upper mount on vehicle and slide the shock into position. Insert the provided 3/8 bolts through upper mount, reservoir bracket and thread into upper mounting plate on shock. Tighten bolts to 35 ft.lbs. using a 9/16 wrench/socket. Be sure to use the shorter 1" bolt in the front hole above the hose fitting.



16. Secure the brake unit. Replace the bolt on the front of coil mount and tighten the nuts in the engine compartment. (IF APPLICABLE)



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.



2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

17. Place the reservoir clamps on the reservoir. Mount the clamps to the bracket using the $\frac{1}{4}$ x $\frac{1}{2}$ button head cap screws included in the kit. Use red locktite and tighten with a 5/32 allen wrench.



18. Center reservoir in the bracket and insert the provided 1" socket head cap screws in the clamps and tighten with a 3/16 allen wrench to secure reservoir. Hose should be pointing back as shown below.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.



2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

19. Bolt the ABS/Brake line bracket to the lower mount. For newer trucks you will use one bracket in the front of the lower mount. For older vehicles you will use a bracket on each side of the lower mount. First mount the angled brackets to the front of the lower mount with the raised end facing out towards the tire. Use the 10-32 x 1/2" button head cap screws to attach the brackets to the lower mount and tighten with an 1/8 Allen wrench. For older vehicles that have lines running on both sides of the lower mount you will attach the remaining two brackets to the back side of lower mount using the provided 10-32 screws.



20. Attach the brake line to the previously installed brake line support by placing the tab in the inward hole and install the 1/4 x 3/4 bolt with washer in the outward hole making sure the head of bolt is on the same side as shock. Install washer and nut and tighten with 7/16 wrench and socket.



IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.




2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com

21. For older vehicles with lines running on both sides of lower mount, use the remaining two brackets on the rear of the lower mount. Attach brackets with provided hardware and attach ABS line to the new support bracket using the provided $\frac{1}{4}$ x $\frac{3}{4}$ bolts.

Photos are for reference only. Brackets must be attached after shock is installed.




IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.



2005+ Ford F250/F350 2.5 & 3.0 Coilover Conversion

King Shocks 12472 Edison Way Garden Grove, CA 92841
714-530-8701 www.kingshocks.com



DOUBLE CHECK ALL HARDWARE:

Make sure everything is installed correctly and all hardware is tight before reinstalling tires. Install tires, remove jack stands and lower vehicle to the ground. Recheck all hardware and lug nuts after 100 miles and periodically after that as part of routine maintenance.

Alignment is critical:

A professional alignment must be performed before driving this vehicle at highway speeds. Do not attempt to drive your vehicle after this install without having the alignment readjusted to factory specs!



King Shocks
12472 Edison Way
Garden Grove, CA 92841
www.kingshocks.com

IMPORTANT: Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701. Most important after the install, Feel the difference and have fun.