



## 1989-1997 Toyota Land Cruiser 80 Series Steering Stabilizer

King Shocks 12472 Edison Way Garden Grove, CA 92841  
714-530-8701 [www.kingshocks.com](http://www.kingshocks.com)

### Parts List:

- 1 – 2.0 Steering Stabilizer (20C001-201)
- 2 – 10mm x 75 Bolts (CB3719)
- 2 – 10mm Nylock Nuts (CN3001)
- 4 – 10mm washers (CW1802)

### Tools Required:

- Metric Wrench/Socket Set
- Ball Joint Tool


**Toyota Land Cruiser 80**  
**OE PERFORMANCE SERIES**



1. Remove factory steering stabilizer. First remove the engine cover plate above the steering stabilizer using a 12mm socket/wrench.



2. Remove the nuts on both ends of the factory steering stabilizer using a 17mm socket/wrench. You may need a ball joint tool or pickle fork to separate the tapered ends from the mounts.



**IMPORTANT:** Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.



1989-1997 Toyota Land Cruiser 80 Series  
Steering Stabilizer

King Shocks 12472 Edison Way Garden Grove, CA 92841  
714-530-8701 [www.kingshocks.com](http://www.kingshocks.com)

3. Install King Steering Stabilizer. Install shaft end to the drag link. Insert the tapered spacer into the factory mount. Install the provided 10mm hardware as shown and tighten nut to 50 ft/lbs.



4. Install cylinder end to the factory mount on the opposite side. Insert the tapered spacer into the factory mount. Install the provided 10mm hardware as shown and tighten nut to 50 ft/lbs.



**IMPORTANT:** Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.



1989-1997 Toyota Land Cruiser 80 Series  
Steering Stabilizer

King Shocks 12472 Edison Way Garden Grove, CA 92841  
714-530-8701 [www.kingshocks.com](http://www.kingshocks.com)

5. Replace the engine cover plate.



**Double check your install, make sure the stabilizer is mounted properly and all hardware is tight. Recheck the hardware after 50 miles and periodically after that as part of routine maintenance.**



**IMPORTANT:** Read all instructions thoroughly from start to finish before beginning the install. Check parts list and make sure all parts are included in the kit. If the instructions are not properly followed severe frame, driveline and/or suspension damage may result. Check for frame and suspension damage prior to installation.

This kit does not require welding. Do not weld on any component. Welding may void the warranty and/or cause the product to fail. If any parts are missing, or for tech assistance; Contact King Off Road Racing Shocks: 714-530-8701 Most important after the install, Feel the difference and have fun.